

iGPSPORT®

USER GUIDE

ZH/EN/JP




LW10

Smart Watch


初步了解您的产品



产品正面



产品背面



充电线

使用步骤

您可以通过如下步骤来使用 LW10:

① 开机 → ② 设置手表 → ③ 开始使用

接下来的这些步骤大约需要占用您 5 至 10 分钟，请选择合适的时间来开始。

① 开机

长按“数码表冠”直到出现启动界面。



提示：如果手表无法开机，可能因长时间放置导致电量耗尽。请充电约 10 分钟后等待自动开机。

② 设置手表

第一步：下载 iGPSport APP

请前往您手机中的应用商店，搜索 iGPSport 并安装。

- Android 系统的手机前往对应的应用商店
- iPhone 前往 App Store



您还可以：

使用手机扫描左侧二维码，快速进入应用商店到达 iGPSport APP，然后选择安装。

第二步：与 APP 配对

进入 iGPSPOrT app，在设备页点击右上角“+”。进入添加设备页，点击手表系列产品进入搜索页面，此时可以点击搜索到的设备进入配对页面，或者点击下方扫码配对，扫描手表上的二维码进入配对页面。按照指引进行配对和设置“LW10”，在完成后即可使用手表。

注意：

1. 请勿直接在手机系统的蓝牙列表中进行配对，避免造成iGPSPOrT无法连接手表。
2. 请允许 iGPSPOrT APP 获得你的手机“蓝牙、位置、相机”等权限，以确保配对成功。



③ 开始使用

触摸屏操作

支持全屏触控（滑动、点触、长按）。



- ↑ 向上滑
- ← 向左滑
- 向右滑
- ↓ 向下滑


表冠与按键

按表冠

1. 息屏时短按表冠点亮屏幕
2. 在主表盘短按表冠进入应用中心
3. 退出应用

旋转表冠

1. 滚动界面视图
2. 调节提示音和电话通话的音量



按键

1. 按下快速进入运动
2. 长按进入 SOS

常用功能



通知中心

在主表盘向下滑出通知中心。



控制中心

在主表盘向上滑出控制中心，即可启用“安静模式、睡眠模式、常亮显示”等功能，也可以快速调节“亮度、音量”等设置。



快捷卡片

在主表盘左右滑动，可以快速切换浏览：建议、活动、心率、睡眠、天气或运动。



切换表盘

在主表盘按住屏幕 1 秒，即可进入切换表盘功能。



记录运动

进入运动，选择一项运动即可开始进行运动记录。

户外运动时，请在空旷区域等待 GPS 连接卫星， 图标闪烁表示正在定位，停止闪烁表示定位成功。



健康测量

佩戴手表时自动测量 心率、睡眠、压力和活动等健康数据，进入应用也可以查看和测量。


安装新表盘

在 iGPSport APP 中，选择设备页，进入表盘市场频道，选择喜欢的表盘安装或者管理已下载表盘。



充电

将充电线缆插入标准的 USB 电源，并将另一端吸附于手表背面的充电触点。成功充电时，手表界面会出现正在充电标识。



- 线缆延伸方向与表冠同侧。
- 请确保采用 5V/500mA 及以上输出的标准 USB 电源。
- 充电前请将手表的充电触点擦拭干净，以去掉残留汗液或水份。

更换表带


移除表带

1. 将拨动杆从导向槽中提起
2. 向表带另一侧推动并保持住
3. 将表带从手表机身轻轻拉出



安装表带

1. 将下图中“A”位置的金属针插入表带衔接处的孔内
2. 将拨动杆向表带另一侧推动并保持住
3. 将表带压入手表机身
4. 拉动表带确认安装成功



穿戴与保养

- 建议每天取下手表约一小时。如果您感到不适或刺激，如发红、刺痛或烧灼感，请摘下手表并让手腕休息。
- 为保持卫生，请定期清洁手表和手腕，尤其是在锻炼和出汗后。避免使用洗手液、沐浴露、洗碗液或清洁湿巾，因为它们会引起皮肤刺激。相反，请使用温和的肥皂和淡水清洁表带。

佩戴注意事项

为了让手表更准确的测量您的数据，需要注意以下两点：

1. 将手表配戴至距离腕骨约两指宽的位置。
2. 手表表带调整到舒适的松紧程度：保持表带与手腕之间的间隙约为一个手指的大小，这样可以手表背部能够贴着皮肤，同时也可以确保舒适度。



注意事项

- 请勿自行更换内置电池，以避免安全风险。
- 强行打开手表外壳，可能导致内部电路短路，造成发热或着火。
- 手表不适用于 60°C 的高温环境，这样可能引起电池泄漏甚至爆炸的风险。
- 本产品严格按照 3ATM 防水检测合格，但不适用于沐浴、潜水、滑水或者其他涉及高温、热气、高速流水的活动；且防水性能并非永久，产品结构被破坏会导致防水性能失效。
- 手表可能由于固件升级，界面或使用方式发生变化是正常的现象，请以产品的升级介绍为准。

产品主要规格

产品名称	LW10
显示屏	1.43" HD AMOLED
分辨率	466 × 466
电池容量	370 mAh
蓝牙连接	Bluetooth 5.3
防水等级	3ATM
卫星定位	支持 GPS/BD
地磁传感器	支持指南针
气压传感器	支持 海拔高度测量
机身尺寸	46.8mm × 46.8mm × 10.8mm
工作温度	-10°C~ 50°C
兼容系统	iOS 13.0 and above, Android 9.0 and above
认证信息	详见手表内监管页面

帮助与指南

常见问题

您在使用产品过程中遇到任何问题，可以前往 iGPSport APP 中“我的-产品售后服务-常见问题”寻找解决方法。

产品说明书

您可以前往 iGPSport APP 中“我的-产品售后服务-产品手册”找到完整的产品说明书。


iGPSPORT®

iGPSPORT®


Your LW10



Front



Back



Charging cable

Steps for Use


You can follow these steps to use LW10:

1 Power On → **2 Set up** → **3 Start Using**

The following steps will take approximately 5 to 10 minutes, please schedule a suitable time.

1 Power On

Press the Digital Crown until the startup screen appears.



Note: If the watch can't power on, it may be because the battery has drained due to long periods of inactivity. Please charge it for approximately 10 minutes and wait for it to power on automatically.

2 Set up the Watch

Step 1: Download the iGPSPORT /iGPSPORT Ride app

Go to the app store on your phone, search for iGPSPORT/iGPSPORT Ride, and install it.

- For Android phones, go to the Google Play.
- For iPhone, go to the App Store.



Also:

You can also scan the QR code on the left to quickly go to the iGPSPORT app in the app store, and install it.

Step 2: Pair with the App

Open the iGPSPOORT/iGPSPOORT Ride app, Find "+" on the device page then enter in. Then enter the smart watch product page. Follow the instructions to pair your "LW10" via Bluetooth or you can scan the QR code in the smart. Then you can start using the watch.

Attentions:

1. To prevent connection issues between the app and the watch, please do not pair directly within the Bluetooth device list in your phone's system settings.
2. To ensure successful pairing, please grant iGPSPOORT/iGPSPOORT Ride App permissions to access Bluetooth, Location, and Camera on your phone.



3 Get Started

Touchscreen Operation

Support full-screen touch
(swipe, tap, touch and hold)




- ↑ Swipe up
- ← Swipe left
- Swipe right
- ↓ Swipe down

Crown and Button

Press

1. Press the digital crown to wake up the screen.
2. Press the digital crown to enter the app center from the watch face screen.
3. Exit the app



Rotate

1. Toggle between screens or navigate through menus.
2. Adjust the volume of prompt tones and phone calls.

Press the button

1. Press to start Workout quickly.
2. Long press to activate SOS.

Common Functions



Notification Center

Swipe down on the watch face screen.



Control Center

To access the Control Center, swipe up on the watch face screen. Enable features like Silent Mode, Sleep Mode, Always-on Display, and adjust brightness and volume swiftly.



Tiles

To switch quickly between the Suggestions, Activity, Heart Rate, Sleep, Weather, or Workout tiles, swipe left or right on the watch face screen.

Install New Watch Faces



Change the Watch Face

To change the watch face, press and hold the screen for 1 second to access the watch face gallery.



Record Workouts

To start your workout recording, access the Workout app and select a specific workout.


For outdoor workouts, wait in an open area until the GPS connects. The blinking icon "📶" shows it's acquiring a location fix and will stop blinking upon success.



Health Metrics Measurement


When wearing the watch, it automatically measures health data such as heart rate, sleep, stress, and activity. You can also view and track this data in the application.

In the iGPSPORT/iGPSPORT Ride app, enter the Face Gallery page in the device page to pick up your preferred watch face.



Charge the Watch

To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while it is being charged.



Note:

Make sure the USB charging plug is at the same side as the crown.


Ensure to use a standard USB power source with an output of 5V/500mA or above.

Prior to charging, ensure to clean the charging contacts of the watch to eliminate any lingering sweat or moisture.

Change the Band


Remove band

1. Lift the spring bar from the groove.
2. Push and hold the spring bar.
3. Pull it out gently to remove the band.



Install band

1. Insert the metal pin at position "A" in the hole.
2. Push and hold the spring bar.
3. Press the band into the body and release the spring bar.
4. Pull the watch band to confirm the firm installation.



Wear and Care

- It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness, tingling, or a burning sensation, take off the watch and rest your wrist.
- To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap, shower gel, dishwashing liquid, or cleaning wipes as they can cause skin irritation. Instead, use mild soap and fresh water to clean the band.

Wear Your Watch

For optimal data accuracy, please observe the following guidelines while wearing the watch:

1. Wear the watch at a position approximately two finger-widths from your wrist bone.
2. For comfort, adjust the band to allow a finger's width between it and your wrist. This ensures both contact and fit.



Precautions

- Do not replace the built-in battery yourself as it may pose a safety risk.
- Avoid forcibly opening the watch case, as it may cause short circuits and overheating.
- Keep the watch away from environments exceeding 60°C to prevent battery leakage or explosion.
- While the product complies with 3ATM waterproof standards, it is not recommended for activities such as bathing, diving, or water skiing that involve high temperatures, steam, or rapid water flow. Note that the waterproof performance may be compromised if the product structure is damaged.
- Be aware that firmware upgrades can lead to interface and usage changes. For detailed information, please refer to the product's upgrade instructions.

Key Specifications

Product Name	LW10
Display	1.43" HD AMOLED
Resolution	466 × 466
Battery Capacity	370 mAh
Wireless Connection	Bluetooth 5.3
Water resistance garde	3ATM
Satellite positioning	Support GPS/BD
Geomagnetic sensor	Support compass
Air pressure sensor	Supports elevation
Body Dimension	46.8mm × 46.8mm × 10.8mm
Working Temperature	-10°C~ 50°C
Compatible Operating Systems	iOS 13.0 and above, Android 9.0 and above

Help and Guide

Frequently Asked Questions

If you encounter any problems while using the product, you can access the "Mine-Service-FAQ" section in the iGPSPORT/iGPSPORT Ride app for assistance.


Product Manual

You can find the complete product manual in iGPSPORT/iGPSPORT Ride app at "Mine-Service-Product manual".


初めて製品を知っていただく



フロント



バック



充電ケーブル

使用手順


LW10を使用する手順は以下のとおりです：

- ① 電源を入れる → ② スマートフォンの設定 → ③ 使用を開始する

以下の手順はおおよそ5分から10分かかりますので、適切な時間を予定してください。

① 電源を入れる

以下の手順はおおよそ5分から10分かかりますので、適切な時間を予定してください。



ウォッチが電源が入らない場合、長時間放置して電池が切れている可能性があります。約10分充電して、自動的に起動を待ってください。

② ウォッチの設定

iGPSPORTアプリをダウンロード

お使いの携帯電話のアプリストアにアクセスし、iGPSPORTを検索してインストールしてください。

- ・ Androidの携帯電話の場合、Google Playにアクセスしてください。
- ・ iPhoneの場合、App Storeにアクセスしてください。



さらに：

携帯電話で左側のQRコードをスキャンし、アプリストアに迅速にアクセスしてiGPSPORTアプリをインストールしてください。

アプリとペアリング

iGPSPORT アプリに入り、デバイスページで右上の「+」をタップします。デバイスを追加するページに入り、ウォッチ製品をタップして検索ページに入ります。ここで検出されたデバイスをタップしてペアリングページに入るか、または下にあるスキャンしてペアリングというボタンを押してウォッチ上のQRコードをスキャンし、ペアリングページに入ります。指示に従って「LW10」をペアリングし、完了したらウォッチを使用できます。

注意事項:

1. スマートフォンのBluetoothリストで直接ペアリングしないでください。これにより、iGPSPORTがウォッチと接続できなくなる可能性があります。
2. ペアリングできるように、iGPSPORTアプリにスマートフォンの'Bluetooth、位置情報、カメラ'などの許可を与えてください。



③ 使用開始

タッチスクリーン操作

全画面タッチ(スワイプ、タップ、長押し)をサポート



- ↑ 上にスワイプ
- ← 左にスワイプ
- 右にスワイプ
- ↓ 下にスワイプ

デジタルクラウンとボタン

デジタルクラウンを押す

1. スリープ状態でデジタルクラウンを短押しして画面を点灯
2. メイン文字盤でデジタルクラウンを短押ししてアプリケーションセンターに入る
3. アプリケーションを終了



デジタルクラウンを回す

ボタンを押す

デジタルクラウンを回す

1. デジタルクラウンを回して画面をスクロールします
2. デジタルクラウンを回して通知音や通話音量を調整します

ボタンを押す

1. ボタンを押して、すばやく運動モードに入る
2. 長押ししてSOSモードに入る

一般的な機能



通知センター

メイン文字盤から下にスワイプして通知センターを表示



コントロールセンター

メイン文字盤から上にスワイプしてコントロールセンターを表示し、'サイレントモード'、'スリープモード'、'常時点灯'などの機能を有効にすることができ、'明るさ'や'音量'などの設定を素早く調整することもできます。



クイックカード

メイン文字盤を左右にスワイプして、'提案'、'アクティビティ'、'心拍数'、'睡眠'、'天気'または'運動'を素早く切り替えることができます。



文字盤を切り替える

メイン文字盤を 1 秒間長押しすると、文字盤を切り替える機能に入ります。



運動の記録

運動モードに入り、任意の運動を選択すると、運動の記録を開始できます。

アウトドアで運動する場合は、開けたエリアでGPS信号を受信するのを待ちます。||| アイコンが点滅していると、位置情報を取得中を示し、点滅が止まると位置情報の取得が成功したことを示します。



健康測定

ウォッチをつけているときに、心拍数、睡眠、ストレス、活動などの健康データが自動的に測定され、アプリにアクセスすることでデータを表示および測定できます。


新しい文字盤をインストール

iGPSPORT アプリ内で、デバイスページを選択し、文字盤マーケットチャンネルに入り、好きな文字盤を選択してインストールするか、すでにダウンロード済みの文字盤を管理します。



チャージ

標準のUSB電源に充電ケーブルを差し込み、もう一方の端をウォッチの背面の充電コンタクトに吸着させます。充電が成功した場合、腕時計の画面に充電中のマークが表示されます。



注意事項

- ・ ケーブルの延長方向はデジタルクラウンと同じ側です。
- ・ 5V/500mA 以上の出力を持つ標準のUSB電源を使用してください。
- ・ 充電前にウォッチの充電コンタクトをきれいに拭いて、残留した汗や水分を取り除いてください"

バンドの交換


バンドを取り外す

1. スプリングバーをガイド溝から持ち上げます
2. バンドの反対側を押し出し、保持します
3. バンドをウォッチ本体から軽く取り外してください



バンドを取り付ける

1. 下図の "A" 位置の金属ピンをバンドの取り付け位置の穴に挿入します。
2. スプリングバーをバンドの反対側に押し出し、保持します。
3. バンドをウォッチ本体に押し込みます。
4. バンドを引っ張り、取り付けが成功したことを確認します。



着用と保守

- ・1日約1時間、ウォッチを外すことをお勧めします。不快感や刺激を感じた場合、赤み、痛み、灼熱感などがあれば、ウォッチを外し、手首を休ませてください。
- ・衛生を保つために、定期的に時計と手首を清潔にし、特に運動や発汗後に注意してください。皮膚刺激を引き起こす可能性があるため、洗剤、ボディウォッシュ、食器洗い液、またはクリーニングウェットを使用しないでください。代わりに、穏やかな石けんと淡水を使用してバンドをきれいにしてください。

装着の注意事項

あなたのデータをより正確に測定するために、次の2つの点に注意する必要があります：

1. 腕骨から約2本分の位置に時計を装着してください。
2. 手首の快適な締め付け感を調整するため、バンドと手首の間に約1本分の隙間を保つように調整してください。これにより、時計の背面が肌に密着し、同時に快適さが確保されます。



注意事項

- ・安全リスクを回避するために内蔵バッテリーを自分で交換しないでください
- ・時計の筐体を無理に開けると、内部回路のショートや過熱、火災の原因となる可能性があります
- ・時計は60°Cの高温環境には適しておらず、これにより電池の漏れや爆発のリスクが発生する可能性があります
- ・この製品は3ATMの防水テストに厳密に合格していますが、入浴、潜水、スキューバダイビング、および高温、蒸気、急流などの活動には適していません。また、防水性能は永久的でなく、製品構造が破損すると防水性能が失われる可能性があります。
- ・時計はファームウェアのアップグレードにより、インターフェースや使用方法が変更される可能性があります。製品のアップグレード情報に従ってください。

製品の主要な仕様

製品名	LW10
ディスプレイ	1.43" HD AMOLED
解像度	466 × 466
バッテリー容量	370 mAh
Bluetooth接続	Bluetooth 5.3
防水等級	3ATM
GPS位置情報	サポート GPS/BD
磁気センサー	サポートコンパス
気圧センサー	サポート高度測定
本体サイズ	46.8mm × 46.8mm × 10.8mm
動作温度	-10°C ~ 50°C
対応システム	iOS 13.0 and above, Android 9.0 and above

ヘルプとガイド

よくある質問

製品を使用中に問題が発生した場合、解決策を見つけるために iGPSPORT アプリ内の「私の-アフターサービス-よくある質問」セクションをご覧ください。

製品マニュアル

iGPSPORT アプリ内の「私の-アフターサービス-製品マニュアル」セクションで完全な製品説明書を見つけることができます。

iGPSPORT®

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

